

**AIRCRAFT FLIGHT REPORT AND MAINTENANCE RECORD
ACCESSORIES DATA**

AIRCRAFT TYPE

YC-122C

SERIAL NO.

49-2884A

PAGE NO.

5 OF 7

NOMENCLATURE AND TYPE A	SERIAL NO. B	LOCATION C	REPLACE EVERY D	PREVIOUS OPERATING TIME E	INSTALLED AT F	REPLACEMENT DUE AT G	REMOVED H	TIME ACCUMULATED I	TOTAL OPERATING TIME J
COMB-HEATER S. PLUG C/PIT	NONE	NOSE COMP	1000:00	00:00	00:00	1250:00 1000:00	1271:46	1271:46	1271:46
CARGO HEATER+ANTIFICER #1	NONE	CARGO COMP	2000:00	00:00	"	2000:00			
" " " #2	"	"	"	00:00	"	"			
" " " #3	"	"	"	00:00	"	"			
FUEL BOOSTER PUMP	DE-100 W	LT. NAC TANK	1200:00	00:00	309:10	1509:10			
" " "	DE-105 W	R. NAC TANK	"	00:00	"	"	1264:05	1264:05	1264:05
" " "	Unknown	LT WING	"	00:00	"	1500:00 1200:00			
" " "	"	RT WING	"	00:00	"	"			
^{oil} FIRE WALL SHUTOFF VALVE	"	L. WING	"	00:00	00:00	"			
^{oil} " " " " "	"	R. WING	"	00:00	"	"			
FUEL CROSS FEED VALVE	"	L. WING	"	00:00	"	"			
" " " "	"	R. WING	"	00:00	"	"			
NACELLE TANK VALVE	"	L. WING	"	00:00	"	"			
" " " "	"	R. WING	"	00:00	"	"			
NACELLE DIRECT SYSTEM VALVE	"	L. WING	"	00:00	"	"			
" " " "	"	R. WING	"	00:00	"	"			
WING TANK VALVE	"	L. WING	"	00:00	"	"			
" " " "	"	R. WING	"	00:00	"	"			
NACELLE BYPASS SELECTOR VALVE	"	L. WING	"	00:00	"	"			
" " " "	"	R. WING	"	00:00	"	"			
WING CROSS FEED VALVE	"	L. WING	"	00:00	"	"			
" " " "	"	R. WING	"	00:00	"	"			
FUEL QUANTITY TRANSMITTER WING	"	L. WING	"	00:00	"	"			
" " " "	"	R. WING	"	00:00	"	"			
" " " " NAC.	"	L. WING	"	00:00	"	"			
" " " " "	"	R. WING	"	00:00	"	"			